

SWAGING MANDRELS FOR 4400-SERIE FITTINGS

9013-00



To control that the swaging has resulted in the right internal collapse. GO-side should pass through the fitting to make sure that the swaging is not overdone. **Product info**

The STOP-side should stop in the middle of the tail to ensure that the swaging is sufficient. **Product info2**

Product group 900

Type Machine accessories

Part No.	Dimension
90130004	1/4"
90130006	3/8"
90130008	1/2"
90130010	5/8"
90130012	3/4"
90130016	1"
90130020	1 1/4"
90130024	1 1/2"
90130032	2"